



SPECIFICATIONS

| | |
|----------------------------|--|
| Product | Rear Sight Installation Tool |
| Part # | RL-TOOL |
| MSRP | \$199.95 |
| Compatible Firearms | Fits almost all* semi-auto pistol slides |
| Frame | 6061 T6 Aluminum with anodized finish |
| Sight Extractor | 8620 Steel, HRC 50-54 |
| Contact Points | Rubber coated metal |

| | |
|---------------|-----------|
| Weight | 1lb. 9oz. |
| Length | 6.5 in. |
| Width | 1.0 in. |
| Height | 3.5 in. |

This ingenious system easily removes the rear sight from the dovetail of almost all* semi-auto pistols and makes installation of the LaserLyte RSL effortless. The RSL Installation Tool is perfect for gunsmiths or gunsmith-minded people and smoothly drifts the sight in or out. No more tapping or banging required.

To use the RSL Installation Tool, tighten down the adjustable clamp screws onto the slide of any gun and ensure it is at the proper height for the sight. Turn the t-handle clamp to push the rear sight out or install the LaserLyte RSL with ease.

LaserLyte's RSL is available for Glock®, Ruger® SR9, Smith & Wesson® M&P, Springfield Armory® XD/XD(M)™ and many 1911 models with Novak® low mount sights. The RSL's ground-breaking new laser design incorporated into the rear sight, compact size and revolutionary performance make it the most extraordinary system LaserLyte has produced. Easy-to-install and easy-to-operate, the new RSL offers a high-power laser with the benefit of not having to replace existing grips or internal stock parts.



—Accuracy Defined—